



# MINI HOT MELT GLUE GUN

TECHNICAL SHEET 06/05/2026

## SMART ADVANTAGES

- Fast, clean and versatile adhesive
- Easy to load and use trigger action
- High bond strength
- Glue is clear and flexible when dry
- Non-toxic, no fumes and very low odour

## DESCRIPTION

**Bostik Mini Glue Gun** is a compact hot melt glue gun. Used with Bostik Mini Glue Sticks, it provides fast, clean and versatile adhesion across many household and craft materials. The trigger action design makes it easy to load and apply hot melt glue with controlled pressure.

**Bostik Mini Glue Gun** instantly bonds most craft and household materials, including fabric, wood, leather, most plastics, ceramics and metal. For foam products such as polystyrene foam, apply adhesive in an "S" pattern to the surface the foam will be bonded to, rather than directly onto the foam.

## TECHNICAL CHARACTERISTICS

<b>Rated voltage</b>	100-240 volts
<b>Rated input power</b>	8-20W
<b>Rated frequency</b>	50/60Hz
<b>Heating Element</b>	Posistor temperature co-efficient (PTC thermistor)
<b>Protection against electric shock</b>	Class II
<b>Equipment mobility</b>	Portable
<b>Type of power connection</b>	Permanently attached flexible cable with plug
<b>Recommended hot melt</b>	Bostik Mini Craft Glue Sticks Diameter: 7.2mm Length: 100mm
<b>Application</b>	Glue is released from gun by trigger action



## APPLICATION

Read and understand the Safety Data Sheet before using this product. SDS can be acquired by visiting [diy.bostik.com/en-AU](http://diy.bostik.com/en-AU)

## SURFACE PREPARATION

1. Locate a pair of pin holes on each side next to the gun nozzle.
2. Attach the metal stand into the pin holes. After attaching the stand, the gun can sit in an upright position when the stand is pulled down or extended. Always use the stand. Never lie the gun down on its side when in use or whilst cooling down as this will cause gun failure.
3. Ensure parts to be glued are dry, clean and free from grease and dust.

## APPLICATION

4. Insert Bostik Mini Glue Stick gently through tunnel at back of gun. Never use excessive force as the glue stick will clog the channel.
5. Plug cord into an electrical outlet and wait 5 minutes to heat up the glue. Ensure glue is hot or glue will not extrude through the gun. Using the glue gun before the glue is fully heated may cause the glue to be forced into the inner chamber of the gun and cause electrical shortage.
6. Apply adhesive by gentle continuous pressure, to the more difficult surface to bond (usually smooth surfaces are more difficult to adhere than rough, porous surfaces). Release trigger to stop flow of glue. Glue does not need to be spread. **Do not touch molten adhesive**, as temperatures around 200°C will cause serious burns.
7. Join surfaces as quickly as possible for optimum bond strength.
8. To bond foam products (polystyrene foam etc.) to another surface, apply adhesive in an "S" pattern to the surface to which the foam will be bonded, rather than directly to the foam.
9. To bond fabrics, use a smaller "S" pattern for additional strength.
10. When you have finished using the gun, switch off and unplug it and allow it to cool completely before storage.
11. Allow the glue stick to remain in the gun – do not remove stick from rear of gun at any time.

The application recommendations are defined by standards of use. They are imperative to respect them, but they don't need a previous try, especially for a first use or inconvenient of support, site or environment. Consult our safety data sheets for precautions to use.

### DISCLAIMER

Bostik offers this Technical Data Sheet ("TDS") for descriptive and informational use only. It is not a warranty, a contract or a substitute for expert or professional advice. Please also see the local product Safety Data Sheet for health and safety considerations.

The statements, technical information, data, and recommendations contained in this TDS are provided 'AS IS' and are not warranted or guaranteed in any way. They represent typical results for the products and are based on Bostik's research only. Since the conditions and methods of use of the products are beyond our control, Bostik expressly disclaims any and all liability and damages of whatever kind or nature that may arise from any use of the products, the results therefrom, or reliance on the information contain herein.

**Bostik Australia Pty Ltd**  
51-71 High Street, Thomastown  
VIC 3074, 1800 BOSTIK  
Tel: 1800 267 845 / [bostik.com.au](http://bostik.com.au)

## REMOVAL

12. Small drops of glue can be easily removed by scraping when cold.
13. Residual glue can be remelted and removed from most bonded surfaces with a warm knife.

## PRODUCT CODES

CODE	NAME
30803736	Mini Glue Gun
30803735	Mini Glue Sticks 7.2mm Blister x 10

## STORAGE

Store in a cool dry area, below 30 °C and out of direct sunlight. Shelf life for the Bostik Mini Craft Glue Sticks is 24 months when stored under recommended conditions.

## HEALTH & SAFETY

Always read the Technical Data Sheet and Safety Data Sheet (SDS) before handling or use. Full product safety information required for safe use is not included in this data sheet. SDS available by request or at [diy.bostik.com/en-AU](http://diy.bostik.com/en-AU)

## PRECAUTIONS IN USE

Recommendations and suggestions are for guidance only, since conditions of use are completely out of our control.

For domestic use only

1. Recommended for light assembly jobs.
2. Do not allow the nozzle of the heated gun to contact any surface as it may cause damage. Hot molten glue may damage some surfaces.
3. Do not leave gun unattended and unplug cord when not in use.
4. Children should only use the gun under adult supervision.
5. Do not use the gun in damp or wet conditions or expose it to rain.
6. Never put any object in the gun other than the glue sticks recommended.
7. The appliance is not to be used by people (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
8. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person to avoid a hazard.

## BOSTIK HOTLINE

Smart help 1800 267 845

